

OPERATING INSTRUCTIONS FOR THE *DG CROP SWEEPER*

Make sure that everybody and everything is clear of the DG Crop Sweeper before operating.

1. Have the fore and aft in back position when starting the SWEEPER.
2. Lift the SWEEPER hydraulics so it is about a foot from the snapping chains.
3. Engage the combine to run and then move the feeder house switch to on and the SWEEPER WILL START.
4. Once the combine is running to speed adjust the speed of the SWEEPER with the dial-o-matic switch on the combine console.
5. In the field adjust the SWEEPER up or down according to crop conditions.
6. If the crop is down and will not slide over the snoots adjust the fore and aft to out position and lower the SWEEPER.
7. If the corn slides over the snoots run the fore and aft back so that the paddles run right behind the rubber ear saver.
8. If the crop is down take off the rubber ear saver. The crop will flow into the combine head better. The crop SWEEPER may also be lowered.
9. Run the height of the SWEEPER wherever the crop flows best.
10. On standing corn or fluff run the SWEEPER about ear high with the paddles running slowly to keep the trash and fluff moving into the auger.
11. When the SWEEPER is not in use move the SWEEPER to a position that allows for the best visibility for the combine operator.

ADJUSTING THE HEIGHT OF THE CROP SWEEPER

1. Threaded screws on top of cylinders
2. Adjusting bolts on the bottom of each arm. Tighten after adjusting.
3. Transport the CROP SWEEPER in the down position with the SWEEPER resting on the corn head.